
Wavelength References for Optical Fiber Communications

Sarah Gilbert

Group Leader, Optical Components Group

Optoelectronics Division

National Institute of Standards and Technology

Boulder, Colorado

Wavelength Division Multiplexing (WDM)

*multiple channels of different wavelengths in the 1500 nm region
(send more information down existing fiber)*

use erbium-doped fiber amplifiers

all optical amplification; preserves wavelength

early systems: ~ 1 nm (~ 100 GHz) channel spacing

closer spacing starting

will likely expand into other wavelength regions



Wavelength Calibration

Need wavelength standards in the 1500 nm region to:

- < *evaluate WDM optical components & set channels*
- < *calibrate fiber Bragg grating sensor systems*

Current industry calibration needs

0.01 - 0.0001 nm accuracy
single point calibration & linearity measurement

NIST Approach:

- *Develop high accuracy wavelength standards for NIST internal calibration*
- *Develop moderate accuracy transfer standards to help industry calibrate instrumentation*

3



Recipe for a Wavelength Standard

Atomic or molecular absorption lines

fundamental resonances

very stable under changing environmental conditions

Good references in the 1500 nm region:

acetylene


hydrogen cyanide

rubidium


noble gas emission lines (neon, krypton, xenon)

4

Transfer Standards Molecular Absorption References



Vibrational combination band
 $\nu_1 + \nu_3$




Vibrational overtone band
 $2\nu_3$

Both mainly H—C stretching vibration + rotational substructure

Acetylene


NIST Standard Reference Material 2517





NIST Standard Reference Material 2517

Absorption of LED light by acetylene ($^{12}\text{C}_2\text{H}_2$)




7



NIST Standard Reference Material 2519

Absorption of LED light by hydrogen cyanide ($\text{H}^{13}\text{C}^{14}\text{N}$)



8


Characteristics of current SRMs:

- < 2 units cover 1510 – 1565 nm
- < linewidths ~ 20 – 100 pm
 - acetylene pressure: 27 kPa (200 Torr)
 - hydrogen cyanide pressure: 13 kPa (100 Torr)
- < line center accuracy certified with 0.6 pm uncertainty includes pressure shift


Have received requests for higher resolution and accuracy

Developing high resolution wavelength reference SRM


- < acetylene $^{12}\text{C}_2\text{H}_2$
- < narrow linewidth
- < line center uncertainty near 0.1 pm \gg 12 MHz
need higher-accuracy measurement of pressure shift



Pressure Shift Measurement



Acetylene Pressure Shift – Line P4



P4 shift = +0.017(2) pm/kPa [0.0023 pm/Torr or -0.29(3) MHz/Torr]

Measured shift for 15 acetylene lines

$+0.008 \text{ pm/kPa} < \mathbf{Dn} < +0.043 \text{ pm/kPa}$
 typically $+0.017 \text{ pm/kPa}$ ($= 2.3 \times 10^{-3} \text{ pm/Torr} = -0.29 \text{ MHz/Torr}$)

For proposed 7 kPa (50 Torr) high-resolution SRM:

- < most lines shifted by about 0.1 pm
- < largest shift 0.3 pm
- < linewidths would be about 6 pm (750 MHz)

Temperature

Modifies pressure shift (changes collision frequency)
 mean velocity $\propto \sqrt{T}$; T in Kelvin

Effect small:
 8% change of pressure shift with 50° C temperature increase

Magnetic Fields

Magnetic moment very small (electrons paired)
 ~ 1/1000 that of atoms | Zeeman splitting negligible
 $\leq \sim 1 \text{ MHz @ } 0.1 \text{ T (1000 G)}$

Electric Fields


No permanent electric dipole moment (symmetry)
 | ordinary Stark effects absent
 AC Stark effect small at moderate pressure ($I_s \sim 10^8 \text{ W/cm}^2$)

NIST High Accuracy Wavelength Standards

Needed for NIST internal calibration

Frequency-doubled 1560 nm light
1560 nm diode laser ‡ fiber amp
‡ PPLN crystal
output at 780 nm » 5 μW

Conducted saturated absorption spectroscopy of rubidium; stabilized laser
very narrow lines
checked wavelength meter
verified 1×10^{-7} accuracy (0.16 pm)




15

NIST Future Work

Wavelength division multiplexing expanding into other λ regions

Current guess: longer λ first (1565 - 1620 nm region)

1300 nm region soon after that? 1400 nm region?



16

Want references with uncomplicated spectra and strong lines (ideally)

Possible References:

1300 nm region

- methane (CH₄) *weak absorption, slightly complex spectrum*
- hydrogen fluoride (HF) *good spectrum but eats practically everything*

1400 nm region: *hydroxide (OH)*


1560-1620 nm region

- carbon monoxide (CO) *weak absorption, good spectrum*
- hydrogen iodide (HI) *good spectrum but some instability*

Artifact References? (wavelength-selective device)


Can drift with temperature, strain, pressure changes, ...


Working on an actively-stabilized artifact reference



Grating at λ_{ref} stabilized to absolute molecular reference near 1550 nm,
 λ_1 FBG at different wavelength – gratings sample same temperature and strain

Example:



**Demonstrated principle**

Stabilized 1549 nm grating

Obtained good stability for 1300 nm grating (few pm)

Expect < 1 pm uncertainty possible

Filed provisional patent, looking for technology transfer opportunities

19

Current WDM C band wavelength calibration

- < 2 SRMs available to for calibration between 1510-1565 nm
0.6 pm uncertainty; single point or linearity calibration
- < High resolution SRM will be available in 2000
narrower lines, uncertainty near 0.1 pm

WDM L band (1565 to ~1620 nm)

- < SRM under development

Other Regions

- < 1300-1500 nm
- < Other? 980 nm?

20