

---

## Intelligent mask Inspection Systems for Next Generation Lithography

Noah Bareket  
Stan Stokowski  
Steve Biellak  
Don Pettibone


KLA-Tencor

Presented at the ATP National Meeting  
San Jose, California  
16 November, 1999



---

## Defect Free Reticles are Critical to Achieving High Device Yields



Courtesy of Photronics

- Killer defects cause yield bust
- Linewidth defects lower IC performance
- Defects narrow the process window


*Defect inspection is a key step in defect elimination*



## Next Generation Lithography Presents Unique Challenges for Mask Inspection



Courtesy of Lucent Technologies




Courtesy of EUV LLC

- Feature size shrink
  - primary features
  - defects
- New defect types
  - substrate and blank defects
  - patterning defects
- New materials
  - transmission is not an option
  - contrast is lower
- New exposure sources
  - which defects print?
  - are all defects visible?

KLA Tencor

NATIONAL INSTITUTE OF STANDARDS AND TECHNOLOGY 3-Dec-99  
 ATP  
 ADVANCED TECHNOLOGY PROGRAM

## When Does the Industry Need NGL?



KLA Tencor

NATIONAL INSTITUTE OF STANDARDS AND TECHNOLOGY 3-Dec-99  
 ATP  
 ADVANCED TECHNOLOGY PROGRAM


## The ATP Project Will Retire the Technical Risks and Accelerate the Introduction of New technology

The Intelligent Mask Inspection Project is a joint effort of these organizations:

- 
  - Build and test a research tool for inspecting NGL masks
  - Develop tools for printability simulation and conduct printability experiments
  - Develop methods and tools for EUV substrate and blank inspection
- 
  - Provide SCALPEL mask models and samples
- 
  - Provide EUV mask modeling, substrates, blanks and patterned masks
- 
  - Develop process for patterning and repairing SCALPEL masks



## How Is a EUV Mask Fabricated and When Do We Inspect It?




Courtesy of EUV LLC



## What Are The Driving Patterned Mask Inspection Requirements?

- Pattern defect detection sensitivity
  - Shape defects near edge
  - Pinholes
  - Linewidth errors
- Throughput (inspection time)




100nm shape defect on edge



3-Dec-99

## Sensitivity Requirements Vary by Mask Type and Lithography Mode




- Advanced lithography (optical proximity correction and phase shift masks) amplifies the defect printability
- Mask defect sensitivity requirements for NGL scale like conventional masks
- NGL requirement is 80nm to 60nm sensitivity for first generation tools
- Scaling rule is for shape defects, 4x masks



3-Dec-99

## The System Design is Driven by The Required Low False Defect Rate




- Required threshold to noise ratio is about 6.5 (150nm pixel size and less than 10 false defects per inspection)
- Required signal to noise ratio is about 10 for 99% detection probability
- The SNR scales as the square of the linear defect size (for most defects)



3-Dec-99

## Increased Sensitivity Comes at the Expense of Inspection Time



- Calculation based on current generation product:
  - 50 Mpixel/sec scanning and processing
  - 100cm<sup>2</sup> inspected area

*Reducing the defect to pixel ratio has high leverage on inspection time!*



3-Dec-99

## Advances in Technology Are Needed to Meet The Emerging Requirements

---

*Extending the capabilities of the current generation of optical inspection tools can be accomplished by:*

- Higher resolution imaging
- Lower noise
- Better detection and disposition algorithms
- Faster processing

*The alternative, non-optical inspection (e-beam, EUV, other), requires significantly more technology development*



## Inspection of Unpatterned EUV Masks Faces Additional Challenges

---


- Shallow defects on the substrate or on the coated blank modulate the wavefront phase, causing printing defects:
  - Cylindrical pit or hillock: 3.4 nm high x 80 nm diameter
  - Scratch: 3.4 nm high x 15 nm wide
  - Step: 1 nm high
- Can optical inspection meet the needs, or is at-wavelength inspection required?
  - Correlate optical and 13-nm blank inspections
  - Determine evolution or mechanism of formation of reflectivity defects
  - Model EUV defect properties in the visible/UV range
  - Determine what defects we missed optically
  - Determine if they are critical defects




## Thorough Inspection Requires Both Bright Field and Dark Field Detection

- Bright-field technology is more adept at finding planar (phase) defects
  - Small pixel size, low throughput
- Dark-field technology provides superior sensitivity for particulate defects
  - Larger pixel size, higher throughput

## Nomarski Differential Interference Contrast (DIC) Detection Provides High Sensitivity on Planar Defects



## A 8 nm Step Height Standard Can Be Measured With the KLA-Tencor SP1 Nomarski DIC Channel




KLA Tencor

NATIONAL INSTITUTE OF STANDARDS AND TECHNOLOGY 3-Dec-99

ATP  
ASTRONOMICAL TECHNOLOGY PROGRAM

## Current Dark-Field Inspection System Sensitivity Will Not Meet the Needs of EUV Inspection



- KLA-Tencor SP1 inspection tool has 60nm sensitivity on silicon
- Sensitivity is reduced on glass substrate


PSL: Polystyrene reference spheres

KLA Tencor

NATIONAL INSTITUTE OF STANDARDS AND TECHNOLOGY 3-Dec-99

ATP  
ASTRONOMICAL TECHNOLOGY PROGRAM

## Dark-Field Inspection in the UV Has the Potential of Meeting the Required Sensitivity



- Sensitivity increases in the UV for both silicon and glass substrates
- Sensitivity of 45nm is obtained with signal level similar to the visible light system

## The Project Develops the Technology in Three Phases

- Phase I (year 1)
  - Build a research tool for NGL reticle inspection
  - Develop software model for NGL-steppers (aerial image)
  - Investigate EUV blank and substrate inspection
- Phase II (year 2)
  - Carry out inspectability/printability studies on the research tool
  - Correlate defects found on the wafer with those on the reticle
  - Establish the feasibility of Optical Inspection of NGL reticles
- Phase III (year 3)
  - Optimize and design a production prototype

## The ATP Project is Well Into the First Phase

---

- The team launched the technical work in mid-June, 1999
- We are modifying a KLA-Tencor UV inspection system to include:
  - High NA optics
  - High throughput image computer
  - Special handling of SCALPEL and EUV masks
  - Special contamination control
- Algorithm development work is focusing on increasing sensitivity and defect discrimination
- We have designed test masks for the printability and sensitivity studies
  
- We continue to collect data on blank and substrate inspection



# SCALPEL Mask Defect Inspection

## SCALPEL Mask Team at Lucent Technologies

### – Anthony Novembre, Technical Manager

- Chris Biddick
- Myrtle Blakey
- Gregory Bogart
- Carlos Caminos
- Reggie Farrow
- Robert Followan
- Joe Griffith
- Leslie Hopkins
- Rich Kasica
- Chester Knurek
- Jessica Li
- J. Alexander Liddle, TMGR
- Leo Ocola
- Paul Orphanos
- Milton Peobody
- Len Rutberg
- Tom Saunders
- Stuart Stanton
- Michael Stohl
- Kristine Teffeau
- Kurt Werder




## Outline

- SCALPEL Mask Introduction
- SCALPEL Mask Commercialization Program
- Optical Inspection of SCALPEL Masks
- Modeling of Defect Printability
- Preliminary Defect Printability Results
- Lucent Contribution to NIST-ATP for Inspection of NGL Masks



# SCALPEL Mask Schematic




Lucent Technologies  
Bell Labs Innovations



Bell Laboratories


# 200 mm SCALPEL Mask




Lucent Technologies  
Bell Labs Innovations



Bell Laboratories



### INITIAL DEMONSTRATION OF SCALPEL MASK PROCESSING CAPABILITY AT A MERCHANT (PHOTRONICS) MASK SHOP



**\*Coded 0.72 mm isolated trench in W/Cr scatterer layer**

**Processing (Photronics)**

- | E-beam write MEBES 4500, 10kV, 7 mC/cm<sup>2</sup>
- | Resist Develop, ZEP-7000, STEAG spray/ spin
- | Pattern transfer Cr, CR-7S APT spray/spin

**Processing (Lucent)**

- | Pattern transfer W, SF<sub>6</sub>/O<sub>2</sub> RIE

\* 0.18 mm at wafer




**Logos:** Lucent Technologies Bell Labs Innovations, Bell Laboratories



## Defect Printability Examples

Case of  $W = 50\text{nm}$ ,  $X_d=200\text{nm}$ , bright,  $C_{\text{def}} = 1$ .



Blur=80nm

Unresolved

Dip=3-4%

Blur=40nm

Resolved

Dip=100%


Lucent Technologies  
Bell Labs Innovations



Bell Laboratories

## Change Gamma from 10 to 5

- Defects Print “Stronger”



Blur = 80nm FWHM

100 nm line

$W = 50\text{ nm}$

$C_{\text{def}} = 1$

- Gamma = 10  $\longrightarrow$  5
- Some CD Sensitivities to Defect Change, Some Don't!
- (lots of dependencies and permutations).
- BAD things (defect on or near edge) generally same or worse as resist contrast falls.

Lucent Technologies  
Bell Labs Innovations



Bell Laboratories


**Example - If the largest tolerable CD error from the defect is 1% (worst case), then:**

- Tolerable full (Cdef = 1) pattern defects must be far from critical objects ( $X_d \gg 100 \text{ nm @ wafer}$ ).
- Pattern edge defects (Cdef = 1) must be  $< CD/8$ .
- Defect repair on or near edge should be nearly perfect (e.g. Cdef = 0.05 post-repair @  $CD/2$ ).
  - **Initial Focused Ion Beam Experiments Promising**
- Even low contrast (Cdef ~ .25) contaminants no good if correlated to an edge ( $X_d < 100\text{nm @ wafer}$ )
- Even small  $CD/8$  pinholes near CD object must be repaired; they're very bright.
- The Inspection improvements From This NIST-ATP Program are needed.




**PROGRAMMED DEFECT DENSITY MASK**


MCNC Manufactured Mask Blank (OL79)  
E-Beam Write: JEOL JBX 6000FS, 50kV, 60nm spot size  
Processing: STEAG Resist Developed, Post Developed Bake  
PlasmaTherm RIE Dry Pattern Transfer



Pinhole (clear) defect



Gap (clear) defect




Bridge (opaque) defect




## SEM MICROGRAPHS OF REPAIRED SCALPEL MASK DEFECTS

Repair tool : Micrion 8000  
Chemistry: Carbon composite



**Defect = 0.70 mm pinhole**



**Defect = 0.70 mm break**


Lucent Technologies  
Bell Labs Innovations



Bell Laboratories

## PRELIMINARY DEFECT AND DEFECT REPAIR PRINTABILITY RESULTS USING SCALPEL PROOF-OF-LITHOGRAPHY TOOL

Mask: MCNC 150 nm SiN , 27.5 nm W, 6 nm Cr      Program defect: 0.70 mm  
Wafer process: ARCHI CA + resist, 0.32 mm thick



Wafer print of clear (break) program defect  
& FIB repaired (C composite) defect

Lucent Technologies  
Bell Labs Innovations



Bell Laboratories

## Lucent Contribution to NIST-ATP for Inspection of NGL Masks

- Provide SCALPEL Masks
- Measuring the Optical Properties of Masks
- Provide Models for Defect Printability
- Experimental Verification of Defect Printability  
Using a SCALPEL Exposure Tool
- Consulting on the Design of Fixtures to Mount  
SCALPEL Masks for Inspection
- Protocol For Handling Masks